

HYDRO-STEAM™ 9150

STEAM BOILER CLEANER, SCALE & CORROSION REMOVER & DISPERSANT

- Cleans New and Used Systems
- Dissolves Oil, Grease, Scale & Sludge
- Recovers Lost Efficiency
- Lowers Heating Bills
- Non-Hazardous Formula
- Helps Control Surging & Carry Over
- Reduce or Eliminate Boiler Noise
- Does Not Contain Acids or Heavy Metals
- Extends the Life of Your Boiler

PACKAGED IN VARIOUS SIZE CONTAINERS

- Safe To Store and Handle
- Environmentally Friendly

HYDRO-STEAM™ 9150 WILL
ENSURE BETTER PERFORMANCE
FROM YOUR STEAM BOILER



HYDRO-STEAM™ 9150

Steam Boiler Cleaner, Scale & Corrosion Remover & Dispersant

DESCRIPTION:

Hydro-Steam™ 9150 is an alkaline, multi-purpose product formulated to gently and effectively remove and disperse scale, corrosion products, and organic matter in residential and small commercial steam boilers.

ADVANTAGES:

Hydro-Steam™ 9150 is an ideal product for "on line" and pre-operational cleaning of old or new steam boiler systems. It is recommended that all new steam boilers be cleaned and passivated with **Hydro-Steam™ 9150** prior to putting the system in service. Properly applied, **Hydro-Steam™ 9150** will solubilize and disperse oil, grease, scale, rust, solder flux, mud and organics that foul and prevent the proper operation of old and new systems. In addition, **Hydro-Steam™ 9150** contains special additives to clean and passivate steam and condensate return lines. **Hydro-Steam™ 9150** is non-corrosive at use concentration and will passivate and protect systems metals from corrosion. **Hydro-Steam™ 9150** contains no acids or heavy metals.

DIRECTIONS:

1. Fill and flush the boiler to remove as many loose contaminants as possible.
2. Refill the boiler to operating level.
3. Add **Hydro-Steam™ 9150** at the rate of 1 quart to every 10 gallons of boiler capacity.
4. **New Boilers:** Run the boiler at normal operating temperature for a minimum of 2-4 hours. The cleaner can be left in the boiler for days if desired.
5. **Used Boilers:** For older boilers, run the boiler for several days or weeks until the water becomes noticeably fouled, drain and flush, repeat the cleaning process until the water remains clean.
6. When cleaning is complete, fill the boiler with clean water and add Rhomar **Boiler Pro™ 903** for scale and corrosion protection.

WARNING:

AVOID CONTACT WITH SKIN OR EYES. DO NOT TAKE INTERNALLY! See MSDS for complete health and safety data. KEEP OUT OF REACH OF CHILDREN.

CONTAINER DISPOSAL:

Triple rinse container and offer for recycling or disposal according to local regulations.

HMIS Rating: Health=2, Flammability=0, Reactivity=0, PPE=B



Distributed by:

Springfield, Missouri 65802
800.543.5975
417.862.2600
www.RhomarWater.com
TalkToUs@RhomarWater.com